



**MARQUE: ACER**

**REFERENCE: ECRAN M87-S01MW**

**CODIC: 3691748**




**NOTICE**



## Acer Projection Screen User Guide

1. Gently and smoothly pull the screen down. When the screen is extended sufficiently, release the handle to lock the screen in place.



2. To store the screen, pull down sharply on the handle to release the lock **a**. Guide the screen up gently **b** until it is fully stowed.

**Note:** Be careful not to damage the screen when pulling it down to release the lock.

